

## SET-UP DATA

Tractive recommendations: Spring preload :14 mm  
Rebound damping :12 clicks



Read more about how to set up the vehicle and how to adjust the adjusters correctly in the Tractive Owner's manual.



## Mounting Instructions

Model : BMW R1100 GS FRONT 1994-

	:Part no.	Pcs.
Contents	:46BM94-R3114	1
	:90100001	1
	:Tractive sticker	2
	:Owner's manual	1
	:	



Before installing this product, check the contents of the kit listed above. If anything is missing, please contact your Tractive dealer.



**Before installing this product, read the Tractive Owner's manual!**

## HOW TO INSTALL

- 1) Put the motorcycle on a workstand so that the rear wheel is off the ground.



Make sure the vehicle is secured so it will not tip

- 2) Remove the front wheel and slide the tank backwards
- 3) Remove the upper and lower attachments of the original shock absorber and remove it.
- 4) Install the Tractive shock absorber and tighten the upper and lower attachments. The bolt for the lower attachment is delivered with the Tractive shock.



Make sure that all screws are tightened to the correct torque.

- 5) Re-install the gas tank and front wheel.

